
## LMS Fowler 3F, Jinty, Parts Identification and check list


2 X 10" length 0.45mm hard brass wire for wiper pickups. 4 X 10" length 0.7mm brass wire. 4 X 10" length 0.9mm brass wire. 1 X 6" length 20 swg soft tinned wire. 3 X turns 22 swg soft tinned wire. 3 X turns 24 swg soft tinned wire. 1" X small bore tube. 1" X 1.8mm copper rod for coupling rod joint pin. 2" X 3.2mm brass rod. 3" X 1.6mm brass rod.






## **Cast Parts**


When I made the four centrifugal moulds (two 1 X spin for larger parts, two 2 X spin for small parts) to produce a full set of castings for the Jinty kit. I took a bakers dozen approach to the number of times I repeated a master in each mould. So you should find extra castings to guard against accidents and mishaps but the quantities listed are the minimum required for the loco.




Jinty Instructions, A4 separate reference sheet page 2, Instruction sheet created October 2013




Jinty Instructions, A4 separate reference sheet page 3, Instruction sheet created October 2013



Jinty Instructions, A4 separate reference sheet page 4, Instruction sheet created October 2013



Jinty Instructions, A4 separate reference sheet page 5, Instruction sheet created October 2013



Jinty Instructions, A4 separate reference sheet page 6, Instruction sheet created October 2013